



NOTE:  
 Radius at bottom will need to be larger than the final radius at the top of the wall to account for block setback. Radius should decrease by 1/2" per block course. (1.5" for every 2 ft. of wall height)  
 Saw cut one block width per course, after the first course, to maintain running bond on both sides of radius.



RidgeRock  
 Retaining Walls Inc.  
 P.O. Box 241233  
 Charlotte, NC 28224  
 704-504-3358  
 Fax: 504-3038

## BLOCK PLACEMENT ON RADIUS

RIDGEROCK DETAILS

1 of 1  
 SHEET NO.

6/2001  
 DATE